

CONTENTS

	Page
SECTION 12 – ENGINE	
Camshaft sprocket retaining tool	99-3
Chain damper setting jig	99-4
Cylinder liner retaining tool	99-3
Jackshaft sprocket retaining tool	99-4
Piston ring clamp	99-3
Rear oil seal pre-sizing tool	99-3
Timing chain tensioner retractor tool	99-4
Timing chain tensioner screwdriver	99-4
Valve timing gauge	99-4
Valve spring compressor	99-3
SECTION 37 – GEARBOX	
Oil seal remover adaptor	99-4
Oil seal remover tool	99-4
SECTION 44 - AUTOMATIC TRANSMISSION	
Bench cradle	99-5
Circlip pliers	99-6
Clutch spring compressors	99-5
Front clutch piston replacer	99-6
Front servo adjuster adaptors	99-6
Mainshaft end float gauge	99-5
Points for circlip pliers	99-7
Pressure test equipment	99-5
Rear clutch piston replacer	99-6
Rear servo adjuster adaptor	99-6
Screwdriver bit adaptors	99-6
Tension wrench	99-6
Tool kit	99-5
Torque screwdriver	99-6



CONTENTS—continued

SECTION 51 — FINAL DRIVE

Differential bearing cone remover	99-7
Differential bearing cone replacer	99-8
Driver handle	99-8
Drive shaft bearing nut wrench	99-8
Hand press	99-7
Pinion bearing cone remover/replacer	99-7
Pinion inner bearing cup replacer	99-8
Pinion oil seal replacer	99-7
Pinion outer bearing cup replacer	99-8
Pinion setting gauge	99-7
Rear hub bearing cone and cup replacer	99-7
Rear hub bearing cone remover	99-8

SECTION 57 — STEERING

Hydraulic pressure test adaptor	99-8
Power steering test set	99-8
Rotor spline seal protector	99-9
Steering joint taper separator	99-8

SECTION 60 — FRONT SUSPENSION

Front suspension setting links	99-9
--	------

SECTION 64 — REAR SUSPENSION

Bearing remover	99-10
Hub puller	99-9
Hub remover	99-9
Hydraulic damper and spring unit dismantling adaptor	99-9
Rear camber setting links	99-10
Rear hub backlash gauge	99-9
Rear hub inner and outer cup remover/replacer adaptor	99-10
Rear hub master spacer and bearing replacer	99-10
Rear hub outer bearing cone remover/replacer	99-10
Rear wishbone pivot dummy shafts	99-10
Torque arm bush remover/replacer	99-10

SECTION 70 — BRAKES


Brake piston retraction tool	99-11
--	-------

SECTION 76 — BODY

Weatherstrip fitting tool	99-11
-------------------------------------	-------




SECTION 12




4833

Valve Spring Compressor J.6118B and Adaptor J.6118C-2.




4835

Valve Timing Gauge C.3993.




4834

Piston Ring Clamp 38.U.3.




4427

Camshaft Sprocket Retaining Tool JD.40.



4832

Rear Oil Seal Pre-sizing Tool JD.17B and Adaptor JD.17B-1.




4856


Cylinder Liner Retaining Tool JD.41.




SECTION 12 (continued)




Chain Damper Setting Jig JD.38.



Timing Chain Tensioner Retractor Tool JD.42 and Support Plate JD.42-1.




Jackshaft Sprocket Retaining Tool J.39.




Timing Chain Tensioner Screwdriver JD.42-2.

SECTION 37




Oil Seal Remover-Main Tool 7657A.




Oil Seal Remover Adaptor L.176A.




SECTION 44




Pressure Test Equipment CBW.1A.




Bench Cradle CWG.35.




Tool Kit CBW.31.



Clutch Spring Compressor CBW.37A.




Mainshaft End Float Gauge CBW.33.




Clutch Spring Compressor CWG.37.

SECTION 44 (continued)




Rear Clutch Piston Replacer CWG.41.

5377




Torque Screwdriver CBW.548.

5382




Front Clutch Piston Replacer CWG.42.

5378




Screwdriver Bit Adaptors CBW.548-1.

5383




Tension Wrench CBW.547A-50.

5379




Front Servo Adjuster Adaptor CBW.548-2A.

5384




Rear Servo Adjuster Adaptor CBW.547A-50-2A.

5380




Front Servo Adjuster Adaptor CBW.548-3.

5385



Screwdriver Bit Adaptor CBW.547A-50-5.


5381




Circlip Pliers 7066.

5386

SECTION 44 (continued)




Circlip Pliers – Points 7066H




Circlip Pliers – Points 7066J


SECTION 51




Pinion Setting Gauge SL.3.




Hand Press SL.14.




Pinion Oil Seal Replacer SL.4.



Pinion Bearing Cone Remover/Replacer SL.14-1.




Rear Hub Bearing Cone and Cup Replacer SL.7.



Differential Bearing Cone Remover SL.14-3.




SECTION 51 (continued)




Rear Hub Bearing Cone Remover SL.14-7.

5409A




5412

Differential Bearing Cone Replacer SL.550-1.




5411

Drive Shaft Bearing Nut Wrench SL.15.




5413

Pinion Outer Bearing Cup Replacer SL.550-4.



5426


Driver Handle 550.



5413A


Pinion Inner Bearing Cup Replacer SL.550-5.

SECTION 57




5389

Power Steering Test Set JD.10.



5390

Hydraulic Pressure Test Adaptor JD.10-3.




5391

Steering Joint Taper Separator JD.24.




SECTION 57 (continued)




Rotor Spline Seal Protector JD.35.

SECTION 60




Front Suspension Setting Links JD.43.


SECTION 64




Hub Remover JD.1D.



****Hydraulic Damper and Spring Unit Dismantling Adaptor JD.11B.****




Hub Puller JD.7A.




Rear Hub Backlash Gauge JD.13.

SECTION 64 (continued)




Rear Wishbone Pivot Dummy Shafts JD.14.

5397




Bearing Remover – Main Tool JD.20A.

5400




Rear Hub Master Spacer and Bearing Replacer JD.15.

5398




Rear Hub Inner and Outer Cup Remover/Replacer Adaptor JD.20A-1.

5401




Rear Hub Outer Bearing Cone Remover/Replacer JD.16.C.

5399



Torque Arm Bush Remover/Replacer JD.21.

5402




Rear Camber Setting Links JD.25.

5403




SECTION 70



5414

Brake Piston Retraction Tool Girling 64932392.

SECTION 76



5404

Weatherstrip Fitting Tool JD.23.

