

ENGINE AND EMISSION CONTROL

CONTENTS

| | | | |
|-------------------------------------|----------|--|----------|
| ENGINE CONTROL SYSTEM | 2 | EMISSION CONTROL SYSTEM | 2 |
| SERVICE SPECIFICATIONS | 2 | ON-VEHICLE SERVICE | 2 |
| | | System Configuration Diagram | 2 |
| | | Vacuum Hose Piping Circuit Diagram | 3 |
| | | CANISTER | 3 |
| | | CATALYTIC CONVERTER | 4 |



ENGINE CONTROL SYSTEM


SERVICE SPECIFICATIONS

| Items | Standard value |
|----------------|----------------|
| Idle speed rpm | 850 ± 50 |

EMISSION CONTROL SYSTEM <MPI>

ON-VEHICLE SERVICE


SYSTEM CONFIGURATION DIAGRAM



9FU0640

*: EVOLUTION-IV only

VACUUM HOSE PIPING CIRCUIT DIAGRAM




CANISTER

REMOVAL AND INSTALLATION

Pre-removal and Post-installation Operation


- Air Cleaner Removal and Installation



Removal steps

1. Vapor hose
2. Purge hose
3. Canister
4. Canister bracket

CATALYTIC CONVERTER REMOVAL AND INSTALLATION



03M0068

Unit: Nm {kgf·m}

Removal steps

1. Spring
2. Heat protector
3. Front exhaust pipe
4. High temperature sensor
<EVOLUTION-IV only>
5. Catalytic converter