



# ELECTRICAL WIRING (EVOLUTION-IV)

## CONTENTS


<b>WIRING HARNESS CONFIGURATION DIAGRAMS</b> .....	2	<b>FOG LAMP</b> .....	42
ENGINE COMPARTMENT .....	2	<b>ROOM LAMP AND LUGGAGE COMPARTMENT LAMP</b> .....	43
DASH PANEL .....	6	<b>TURN-SIGNAL LAMP AND HAZARD LAMP</b> .....	44
FLOOR, ROOF, AND SEAT .....	12	<b>STOP LAMP</b> .....	47
LUGGAGE COMPARTMENT .....	14	<b>BACK-UP LAMP</b> .....	48
<b>SINGLE PART INSTALLATION POSITION</b> .....	16	<b>HORN</b> <VEHICLES WITHOUT SRS AIR BAG> .	49
RELAY .....	16	<b>OIL PRESSURE WARNING LAMP</b> .....	50
ECU .....	17	<b>CENTRAL DOOR LOCKING SYSTEM &lt;VEHICLES WITH KEYLESS ENTRY SYSTEM&gt;</b> .....	52
SENSOR .....	18	<b>HEATER AND MANUAL AIR CONDITIONER</b> .....	56
SOLENOID VALVE .....	20	<b>FULLY AUTOMATIC AIR CONDITIONER</b>	62
CHECK CONNECTOR AND SPARE CONNECTOR .....	21	<b>WINDSHIELD WIPER AND WASHER &lt;INTERMITTENT WIPER&gt;</b> .....	70
FUSIBLE LINK AND FUSE .....	22	<b>REAR WIPER AND WASHER</b> .....	71
GROUND CABLE .....	22	<b>DEFOGGER AND DOOR MIRROR HEATER &lt;VEHICLES WITHOUT FULLY AUTOMATIC AIR CONDITIONER&gt;</b> .....	72
GROUND .....	22	<b>DEFROGGER AND DOOR MIRROR HEATER &lt;VEHICLES WITH FULLY AUTOMATIC AIR CONDITIONER&gt;</b> .....	74
<b>CIRCUIT DIAGRAM</b> .....	23	<b>SPARE CONNECTOR FOR RADIO</b> .....	76
CENTRALIZED JUNCTION .....	23	<b>RADIO &lt;4-SPEAKER, 6-SPEAKER&gt;</b> ....	78
POWER DISTRIBUTION SYSTEM .....	24	<b>ANTI-LOCK BRAKE SYSTEM (ABS)</b> ....	80
STARTING SYSTEM .....	29	<b>ACTIVE YAW CONTROL SYSTEM (AYC)</b>	86
IGNITION SYSTEM .....	30	<b>INTERCOOLER WATER SPRAY SYSTEM</b>	92
CHARGING SYSTEM .....	31		
ENGINE CONTROL SYSTEM .....	32		
COOLING SYSTEM .....	38		
TAIL LAMP, POSITION LAMP, LICENSE PLATE LAMP AND LIGHTING MONITOR ALARM BUZZER .....	40		

# WIRING HARNESS CONFIGURATION DIAGRAMS

## ENGINE COMPARTMENT





- |             |                              |            |  |
|-------------|------------------------------|------------|--|
| A-01 (2-B)  | Brake fluid level switch     | A-20 (4-B) | Windshield wiper motor                           |
| A-03 (1-B)  | Noise condenser              | A-21 (8-B) | Hydraulic unit <vehicles with ABS>               |
| A-04 (1)    | Alternator                   | A-22 (2-B) | Hydraulic unit <vehicles with ABS>               |
| A-05 (4-GR) | Alternator                   | A-23 (2-B) | Waste gate solenoid valve                        |
| A-09 (1-B)  | Starter                      | A-25 (7-B) | Air flow sensor                                  |
| A-10 (1)    | Starter                      | A-26 (2-B) | Front speed sensor (LH)<br><vehicles with ABS>   |
| A-12 (2-B)  | Fuel pressure solenoid valve | A-28 (8-B) | Control harness and front harness<br>combination |
| A-16 (4-B)  | Throttle position sensor     |            |  |
| A-18 (6-B)  | Idle speed control servo     |            |  |
| A-19 (3-B)  | Vehicle speed sensor         |            |  |




36M0149

A-29 (2-B)	Front harness and battery harness combination	A-39 (1-B)	Engine coolant temperature gauge unit
A-33 (1)	Horn (LH)	A-45 (1)	Horn (RH)
A-34 (1)	Horn (LH)	A-46 (1)	Horn (RH)
A-35 (2-BR)	Outside air temperature sensor <vehicles with fully automatic air conditioner>	A-49 (2-BR)	Dual pressure switch
A-38 (2-B)	Engine coolant temperature sensor	A-50 (2-B)	Front speed sensor (RH) <vehicles with ABS>




- |             |                                  |             |   |
|-------------|----------------------------------|-------------|---|
| A-51 (3-B)  | Crank angle sensor               | A-80X (5)   | Horn relay <vehicles with SRS air bag>          |
| A-52 (1-B)  | Oil pressure switch              | A-82X (5)   | Radiator fan relay (LO)                         |
| A-53 (2-B)  | Injector (No.1)                  | A-84X (5)   | Headlamp relay                                  |
| A-54 (2-B)  | Injector (No.2)                  | A-86X (4)   | Alternator relay                                |
| A-55 (2-B)  | Injector (No.3)                  | A-88 (6-B)  | Control harness and battery harness combination |
| A-56 (2-B)  | Injector (No.4)                  | A-89 (2-BR) | Front turn signal lamp (LH)                     |
| A-63 (2-B)  | O <sub>2</sub> sensor            | A-90 (3-B)  | Headlamp (LH)                                   |
| A-72 (2-B)  | Back-up lamp switch              | A-91 (2)    | Position lamp (LH)                              |
| A-73 (1-L)  | Engine speed detection connector | A-92 (2-B)  | Fog lamp (LH)                                   |
| A-74 (1-B)  | Fuel pump check connector        | A-94 (4-GR) | Radiator fan motor                              |
| A-76 (6)    | Valve relay <vehicles with ABS>  | A-96 (2-GR) | Knock sensor                                    |
| A-77 (5)    | Motor relay <vehicles with ABS>  |             |   |
| A-78 (2-GR) | Side turn signal lamp (LH)       |             |   |




36M0149

- |              |                                    |              |                                      |
|--------------|------------------------------------|--------------|--------------------------------------|
| A-97 (3-B)   | Camshaft position sensor           | A-114X (4)   | Condenser fan relay (HI)             |
| A-99 (2-B)   | Condenser fan motor                | A-116X (4)   | A/C compressor relay                 |
| A-101 (1)    | Power steering oil pressure switch | A-117 (2-GR) | Side turn signal lamp (RH)           |
| A-102 (1)    | Spare connector for fog lamp       | A-123 (5-B)  | Fuel pump relay No.2                 |
| A-103 (2-B)  | Fog lamp (RH)                      | A-124 (6-B)  | Fuel pump resistor                   |
| A-104 (2)    | Position lamp (RH)                 | A-125 (2-B)  | Resistor (for injector)              |
| A-105 (3-B)  | Headlamp (RH)                      | A-126 (5-B)  | AYC relay                            |
| A-106 (1-B)  | A/C compressor assembly            | A-127 (2-B)  | Secondary air control solenoid valve |
| A-107 (2-BR) | Front turn signal lamp (RH)        | A-128 (2-GR) | Condenser fan motor                  |
| A-110 (3-GR) | Ignition coil 1                    | A-129 (2-B)  | Water spray motor                    |
| A-111 (3-GR) | Ignition coil 2                    | A-130 (3-B)  | Water motor                          |
| A-112X (4)   | Radiator fan relay (HI)            | A-131 (1-B)  | Noise condenser                      |
| A-113X (4)   | Condenser fan relay (LO)           |              |                                      |

DASH PANEL




- |             |   |           |   |
|-------------|---|-----------|---|
| B-01 (2-R)  | Passenger seat air bag module (squib)   | B-07 (8)  | Blower switch   |
| B-02 (2)    | Heater water temperature sensor   |           | <vehicles with manual air conditioner>                |
| B-03 (2-B)  | Air thermo sensor <vehicles with fully automatic air conditioner>                                     | B-08 (25) | Meter and gauge                                       |
| B-04 (20-B) | A/C-ECU <vehicles with fully automatic air conditioner>   | B-09 (25) | Meter and gauge                                       |
| B-05 (16-B) | A/C-ECU <vehicles with fully automatic air conditioner>   | B-10 (22) | Body harness and front door harness (RH) combination  |
| B-06 (6)    | Air outlet change-over damper motor and potentiometer <vehicles with fully automatic air conditioner> | B-11X (8) | Rear intermittent wiper relay                         |
|             |   | B-13X (5) | Power window relay                                    |
|             |   | B-15 (20) | Front harness and body harness combination            |
|             |   | B-16 (6)  | Front harness and body harness combination            |
|             |   | B-17 (14) | Front harness and body harness combination <ABS, AYC> |
|             |   | B-18 (19) | Jumper connector (1)                                  |



36M0157


- |             |   |           |   |
|-------------|---|-----------|---|
| B-19 (22)   | Body harness and instrument panel harness combination | B-33 (2)  | Blower motor<br><vehicles with fully automatic air conditioner>   |
| B-21 (2)    | Stop lamp switch (driver side)                        | B-34 (4)  | Blower high speed relay <vehicles with fully automatic air conditioner>   |
| B-22 (16-B) | Diagnosis connector                                   | B-35 (22) | Body harness and front door harness (LH) combination  |
| B-24 (26-Y) | ABS-ECU   | B-36 (2)  | Inside and outside air change-over damper motor <vehicles with fully automatic air conditioner>                               |
| B-25 (16)   | ABS-ECU   | B-37 (4)  | Power transistor <vehicles with fully automatic air conditioner> or resistor <vehicles with heater or manual air conditioner> |
| B-26 (2-B)  | Diode (for ABS circuit)                               |           |   |
| B-27 (4)    | Engine control relay                                  |           |   |
| B-28 (4)    | Fuel pump relay                                       |           |   |
| B-29 (4-B)  | A/T relay   |           |   |
| B-30 (14)   | Radio or spare connector for radio                    |           |   |
| B-31 (1)    | Glass antenna amplifier                               |           |   |
| B-32 (19-B) | Jumper connector (5)                                  |           |   |

Connector  
symbol  
**B**  
-38  
thru  
-65  
and  
-94  
thru  
-97



- B-38 (2) Sunlight sensor <vehicles with fully automatic air conditioner>
- B-39 (6) Air mix damper motor and potentiometer <vehicles with fully automatic air conditioner>
- B-40 (3) Automatic compressor ECU <vehicles with manual air conditioner>
- B-41 (8) A/C switch <vehicles with manual air conditioner>
- B-42 (2) Blower switch illumination lamp <vehicles with heater or manual air conditioner>

- B-43 (6-B) Defogger switch <vehicles with heater or manual air conditioner>
- B-44 (6) Body harness and roof harness combination <vehicles with sunroof>
- B-45 (2-B) Diode (for keyless entry system circuit)
- B-46 (2) Spare connector for fog lamp switch <vehicles without fog lamp>
- B-48 (14) Jumper connector (2)
- B-49 (14) Jumper connector (3)
- B-50 (14-L) Jumper connector (4)
- B-51 (21-Y) SRS-ECU




- B-52 (16-B) Control harness and body harness combination <vehicles with ABS>
- B-59 (26-Y) Engine-ECU
- B-60 (16-Y) Engine-ECU
- B-61 (12-Y) Engine-ECU
- B-62 (22-Y) Engine-ECU
- B-63 (2) Blower motor <vehicles with heater or manual air conditioner>
- B-64 (13) Control harness and body harness combination


- B-65 (16-B) Control harness and body harness combination
- B-94 (13) Control harness and body harness combination <vehicles with AYC>
- B-95 (26-Y) AYC-ECU
- B-96 (16) AYC-ECU
- B-97 (2) Foot lamp

Connector  
symbol  
**B** -66  
thru  
-89  
and  
-98

<Junction block>




36M0001



36M0002

<Steering column>





36M0156

- |             |   |            |   |
|-------------|---|------------|---|
| B-66 (2)    | Junction block and roof harness combination             | B-79 (12)  | Junction block and ETACS-ECU combination, or junction block and ECU combination |
| B-67 (11)   | Junction block and front harness combination            | B-80 (13)  | Junction block and body harness combination                                     |
| B-68 (3)    | Turn signal / hazard flasher unit                       | B-81 (12)  | Column switch   |
| B-69 (14)   | Junction block and instrument panel harness combination | B-82 (2-R) | Clock spring <vehicles with SRS air bag>  |
| B-70 (4)    | Dedicated fuse (for sunroof circuit)                    | B-83 (6)   | Ignition switch   |
| B-71 (5)    | Defogger relay  | B-84 (5)   | Key reminder switch   |
| B-72 (5)    | Blower relay  | B-85 (6)   | Column switch   |
| B-73 (1)    | Junction block and front harness combination            | B-86 (10)  | Column switch   |
| B-74 (10)   | Junction block and body harness combination             | B-87 (3)   | Clock spring (SRS) <vehicles with dual horn>                                    |
| B-75 (10-B) | Junction block and body harness combination             | B-88 (2)   | Driver seat air bag module (squib)  |
| B-76 (8)    | Junction block and body harness combination             | B-89 (1)   | Horn switch <vehicles with SRS air bag>   |
| B-77 (8)    | ETACS-ECU   | B-98 (5)   | Steer sensor <vehicles with AYC>  |
| B-78 (4)    | Junction block and body harness combination             |            |   |


NOTES

FLOOR, ROOF, AND SEAT





- |           |   |             |   |
|-----------|---|-------------|---|
| D-01 (20) | Receiver<br><vehicles with keyless entry system>    | D-09 (1)    | Map lamp  |
| D-02 (2)  | Seat belt switch                                    | D-10 (18)   | Sunroof ECU   |
| D-03 (2)  | Front door switch (RH)                              | D-11 (2-GR) | Room lamp <vehicles without sunroof>                |
| D-04 (10) | Body harness and fuel harness combination           | D-12 (8)    | Sunroof motor                                       |
| D-05 (6)  | Body harness and rear door harness (RH) combination | D-13 (3-B)  | Fuel gauge unit (sub)                               |
| D-06 (22) | Body harness and rear harness combination           | D-14 (2-B)  | Rear speed sensor (LH)<br><vehicles with ABS>       |
| D-07 (6)  | Sunroof switch                                      | D-16 (6)    | Body harness and rear door harness (LH) combination |
| D-08 (8)  | Room lamp <vehicles with sunroof>                   | D-17 (2)    | Front door switch (LH)                              |
|           |   | D-18 (6)    | Fuel gauge unit (main)                              |

<Power seat>



- |            |  |            |  |
|------------|--|------------|--|
| D-19 (2-B) | Rear speed sensor (RH)<br><vehicles with ABS>                    | D-25 (2)   | Body harness and power seat harness<br>combination and power seat switch |
| D-20 (3-B) | Acceleration sensor (longitudinal)<br><vehicles with ABS or AYC> | D-26       | Slide motor  |
| D-21 (1-B) | Parking brake switch   | D-27 (2)   | Body harness and rear harness combina-<br>tion <vehicles with AYC>       |
| D-22 (2-B) | High temperature sensor  | D-31 (2)   | Water spray switch   |
| D-23       | Reclining motor  | D-32 (3-B) | Acceleration sensor (lateral)<br><vehicles with AYC>                     |
| D-24       | Slide limit switch   |            |  |

LUGGAGE COMPARTMENT




- |             |  |             |  |
|-------------|--|-------------|--|
| F-01 (1-B)  | Defogger (-) <vehicles without choke coil>         | F-17 (1-B)  | Luggage compartment lamp switch                          |
| F-02 (1-B)  | Defogger (-) <vehicles with choke coil>            | F-18 (2-GR) | Licence plate lamp (LH)                                  |
| F-03 (2)    | Choke coil   | F-20 (6)    | Rear combination lamp (LH)                               |
| F-04 (3)    | Choke coil   | F-23 (2-B)  | Rear speaker (LH)  |
| F-05 (2)    | Luggage compartment lamp                           | F-24 (1)    | Glass antenna <vehicles without diversity glass antenna> |
| F-06 (2)    | High mounted stop lamp (installed on rear shelf)   | F-25 (1)    | Glass antenna  |
| F-08 (2-B)  | Rear speaker (RH)                                  | F-26 (1-B)  | Rear door switch (LH)                                    |
| F-09 (1-B)  | Defogger (+) <vehicles with choke coil>            | F-27 (3-B)  | Proportioning valve <vehicles with AYC>                  |
| F-10 (1-B)  | Defogger (+) <vehicles without choke coil>         | F-28 (2-B)  | Direction valve (LH) <vehicles with AYC>                 |
| F-11 (3)    | Rear wiper motor                                   | F-29 (2-B)  | Direction valve (RH) <vehicles with AYC>                 |
| F-12 (1-B)  | Rear door switch (RH)                              | F-30 (8-B)  | Rear harness and AYC harness combination                 |
| F-13 (2)    | High mounted stop lamp (installed on rear spoiler) | F-31 (2-B)  | Accumulator pressure switch <vehicles with AYC>          |
| F-15 (6)    | Rear combination lamp (RH)                         | F-32 (2-B)  | AYC motor  |
| F-16 (2-GR) | Licence plate lamp (RH)                            |             |  |

NOTES




# SINGLE PART INSTALLATION POSITION

## RELAY

Name	Symbol	Name	Symbol
AYC relay	B	Fuel pump relay No.2	B
Condenser fan motor relay (HI)	A	Radiator fan motor relay (HI)	A
Condenser fan motor relay (LO)	A	Radiator fan motor relay (LO)	C




16M0429




**ECU**

Name	Symbol
AYC-ECU	A









B21A066








16M0423

**SENSOR**



Name	Symbol	Name	Symbol
Acceleration sensor (lateral) <vehicles with AYC>	I	Knock sensor	B
Acceleration sensor (longitudinal) <vehicles with ABS and AYC>	I	Outside air temperature sensor <vehicles with fully automatic air conditioner>	F
Air flow sensor	D	O <sub>2</sub> sensor	E
Camshaft position sensor	G	Steering angle sensor <vehicles with AYC>	H
Crank angle sensor	A	Throttle position sensor	C
Engine coolant temperature sensor	G		






**SOLENOID VALVE**

Name	Symbol	Name	Symbol
Direction valve <vehicles with AYC>	D	Secondary air control solenoid valve	A
Fuel pressure solenoid valve	B	Waste gate solenoid valve	C
Proportioning valve <vehicles with AYC>	D		




0040011


16M0429




16M0433



16M0405




16M0116




16M0409

# CHECK CONNECTOR AND SPARE CONNECTOR

Name	Symbol	Name	Symbol
Engine speed check connector	A	Fuel pump check connector	A




16M0429





16M0407


# FUSIBLE LINK AND FUSE




16M0429




# GROUND CABLE




16M0429




GROUND




36M0017




16M0094










16M0135



16M0424



16M0076



# CIRCUIT DIAGRAM


## CENTRALIZED JUNCTION

### FUSIBLE LINK

No.	Circuit protected	Type	Housing color	Rated capacity (A)
10	Active yaw control system	Screw-in type	Yellow	60

Fuse box directly attached on battery

<Vehicles with AYC>




16M0144

### CENTRALIZED RELAY


Connector No.	Name	Connector No.	Name
A-82X	Radiator fan motor relay (LO)	A-113X	Condenser fan motor relay (LO)
A-112X	Radiator fan motor relay (HI)	A-114X	Condenser fan motor relay (HI)

Relay box in engine compartment




16M0141

(A/C relay box)



16M0142


POWER DISTRIBUTION SYSTEM




(A-84X)

(B-16)






POWER DISTRIBUTION SYSTEM (CONTINUED)




(B-67)


(B-76)

(B-83)







POWER DISTRIBUTION SYSTEM (CONTINUED)



(B-73) (B-76)





STARTING SYSTEM








ENGINE CONTROL SYSTEM





(B-60)

31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46

(B-62)

71	72	73	74	75	76	77	78	79	80	81
82	83	84	85	86	87	88	89	90	91	92

(B-64)

1	2	3	▽	4	5	6
7	8	9	10	11	12	13

(B-65)

1	2	3	▽	4	5	6	7	
8	9	10	11	12	13	14	15	16

(B-73)

1
---


(B-75)

1	2	3	▽	4	5	6	7	
8	9	10	11	12	13	14	15	16

(B-76)

1	2	3	4
5	6	7	8





- CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM>
- FULLY AUTOMATIC AIR CONDITIONER

(B-32)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-50)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

(B-61)

51	52	53	54	55	56
57	58	59	60	61	62


(B-62)

71	72	73	74	75	76	77	78	79	80	81
82	83	84	85	86	87	88	89	90	91	92

(B-65)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					





(B-59)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

(B-60)

31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46

(B-61)

51	52	53	54	55	56
57	58	59	60	61	62

(B-62)

71	72	73	74	75	76	77	78	79	80	81
82	83	84	85	86	87	88	89	90	91	92


(B-64)

1	2	3	4	5	6	
7	8	9	10	11	12	13

(B-65)

1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16





(B-59)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26



(B-67)


1	2	3	4
5	6	7	8
9	10	11	

(B-76)

1	2	3	4
5	6	7	8


# TAIL LAMP, POSITION LAMP, LICENSE PLATE LAMP AND LIGHTING MONITOR ALARM BUZZER








# ROOM LAMP AND LUGGAGE COMPARTMENT LAMP







B-68





B-69

B-75


B-76

B-86

C-02



TURN-SIGNAL LAMP AND HAZARD LAMP (CONTINUED)



(B-09)

1	2	3	4	5	6	7	8	9	10	11	12
									13		
14	15	16	17	18	19	20	21	22	23	24	25

(B-50)

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18

(B-75)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16	17	18	19	20	21

(B-80)

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16	17	18

(B-86)

1	2	3	4
5	6	7	8
9	10	11	12

(D-06)

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30


(F-15)

1	2
3	4
5	6


(F-20)

1	2
3	4
5	6

STOP LAMP




(B-15)



(B-21)



(D-06)



(F-06)



(F-13)




(F-15)



(F-20)




# BACK-UP LAMP




(A-72)



(B-64)




(B-74)



(B-76)



(D-06)





(F-15)








(F-20)



**HORN <VEHICLES WITHOUT SRS AIR BAG>**













OIL PRESSURE WARNING LAMP










NOTES


**CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM>**






CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM> (CONTINUED)






(B-80)




(D-01)



(D-03)



(D-06)




(D-08)





(D-09)




(D-11)




HEATER AND MANUAL AIR CONDITIONER






(B-49)




(B-63)



(B-67)



(B-69)




(B-72)



(B-73)





(B-75)



(B-76)





HEATER AND MANUAL AIR CONDITIONER (CONTINUED)






HEATER AND MANUAL AIR CONDITIONER (CONTINUED)




NOTES

FULLY AUTOMATIC AIR CONDITIONER




(B-04)




(B-05)



(B-15)



(B-19)



(B-33)



(B-34)




(B-37)




(B-39)




(B-80)




(B-86)







(B-48)




(B-49)



(B-67)



(B-69)




(B-72)



(B-73)





(B-75)




(B-76)




FULLY AUTOMATIC AIR CONDITIONER (CONTINUED)








- ANTI-LOCK BRAKE SYSTEM
- ENGINE CONTROL SYSTEM
- CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM>







FULLY AUTOMATIC AIR CONDITIONER (CONTINUED)







FULLY AUTOMATIC AIR CONDITIONER (CONTINUED)





NOTES


**WINDSHIELD WIPER AND WASHER <INTERMITTENT WIPER>**




REAR WIPER AND WASHER




# DEFOGGER AND DOOR MIRROR HEATER <VEHICLES WITHOUT FULLY AUTOMATIC AIR CONDITIONER>




<b>(B-10)</b>	<b>(B-15)</b>	<b>(B-19)</b>	<b>(B-35)</b>	<b>(B-43)</b>	<b>(B-48)</b>		
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6	1 2 3 4 5 6 7 8 9 10 11 12 13 14		
<b>(D-06)</b>	<b>(E-01)</b>	<b>(E-17)</b>	<b>(F-01)</b>	<b>(F-02)</b>	<b>(F-03)</b>	<b>(F-04)</b>	<b>(F-09)</b>
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7	1 2 3 4 5 6 7	1	1	1 2	1 2 3	1



(B-50)



(B-69)




(B-71)




(B-73)



(B-74)




(B-75)




(B-76)



(B-80)




(B-86)



(F-10)







(B-76)

1	2	3	4
5	6	7	8

(B-80)

1	2	3	4	5	6	
7	8	9	10	11	12	13

(D-06)

1	2	3	4	5	6	7	8	9	10		
11	12	13	14	15	16	17	18	19	20	21	22

(E-01)

1	2	3	
4	5	6	7

(E-17)

1	2	3	
4	5	6	7

(F-01)

1
---


(F-02)

1
---


(F-03)

1	2
---	---

SPARE CONNECTOR FOR RADIO



<b>(A-19)</b> 1 2 3	<b>(B-10)</b> 1 2 3 4 5 M 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	<b>(B-15)</b> 1 2 3 4 M 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20	<b>(B-19)</b> 1 2 3 4 5 M 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	<b>(B-30)</b> 1 2 3 M 4 5 6 7 8 9 10 11 12 13 14	<b>(B-31)</b> 1	
<b>(B-75)</b> 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	<b>(B-76)</b> 1 2 3 4 5 6 7 8	<b>(B-80)</b> 1 2 3 4 5 6 7 8 9 10 11 12 13	<b>(B-86)</b> 1 2 M 3 4 5 6 7 8 9 10	<b>(D-06)</b> 1 2 3 4 5 M 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	<b>(E-11)</b> 1 2	<b>(E-18)</b> 1 2



(B-35)

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22								

(B-48)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-49)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-64)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-69)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-73)

1
---

(B-74)

1	2	3	4	5
6	7	8	9	10

(F-08)

1
2


(F-23)

1
2


(F-25)


1
2

RADIO <4-SPEAKER, 6-SPEAKER>




\*1:  
\*2:





(B-35)	(B-48)	(B-49)	(B-64)	(B-69)	(B-73)	(B-74)
1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22	1 2 3 4 5 6 7 8 9 10 11 12 13 14	1 2 3 4 5 6 7 8 9 10 11 12 13 14	1 2 3 4 5 6 7 8 9 10 11 12 13	1 2 3 4 5 6 7 8 9 10 11 12 13 14	1	1 2 3 4 5 6 7 8 9 10
(E-16)	(E-18)	(F-08)	(F-23)	(F-24)	(F-25)	
1 2	1 2	1 2	1 2	1 2	1 2	

ANTI-LOCK BRAKE SYSTEM (ABS)



(B-15)

1	2	3	4	5	6	7	8	9		
10	11	12	13	14	15	16	17	18	19	20

(B-21)

1
2

(B-24)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

(B-25)

31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46

(B-32)


1	2	3	4	5	6	7	8			
9	10	11	12	13	14	15	16	17	18	19

(B-49)


1	2	3	4	5	6		
7	8	9	10	11	12	13	14

(B-96)


31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46



(B-52)




(B-65)




(B-73)



(B-74)




(B-75)




(B-76)




(B-95)




ANTI-LOCK BRAKE SYSTEM (ABS) (CONTINUED)




(A-26)	(A-50)	(A-76)	(A-77)	(B-08)	(B-09)	(B-17)	(B-24)
1 2	1 2	1 2 3 4 5 6	1 2 3 4 5	31 32 33 34 35 36 37 38 39 40 41 42 43	1 2 3 4 5 6 7 8 9 10 11 12 13	1 2 3 4 5 6 7 8 9 10 11 12 13 14	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26




(B-25)



(B-52)




(B-75)



(B-76)



(D-04)



(D-14)




(D-19)



(D-20)



ANTI-LOCK BRAKE SYSTEM (ABS) (CONTINUED)




(A-21)



(A-22)



(B-22) FRONT VIEW




(B-24)




(B-25)




(B-32)



(B-50)



(B-60)










NOTES





ACTIVE YAW CONTROL SYSTEM (AYC) (CONTINUED)





(B-52)

1	2	3	▽	4	5	6	7	
8	9	10	11	12	13	14	15	16

(B-65)

1	2	3	▽	4	5	6	7	
8	9	10	11	12	13	14	15	16

(B-95)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

(B-96)

3	1	2	3	3	4	3	5	3	6	3	7	3	8		
3	9	4	0	4	1	4	2	4	3	4	4	4	5	4	6

(B-98)

1	2	3	4	5
---	---	---	---	---

(D-04)

1	2	3	4		
5	6	7	8	9	10







(D-14)

1	2
---	---

(D-19)

1	2
---	---

ACTIVE YAW CONTROL SYSTEM (AYC) (CONTINUED)





INTERCOOLER WATER SPRAY SYSTEM

