



ELECTRICAL WIRING (EVOLUTION-V)

CONTENTS


WIRING HARNESS CONFIGURATION DIAGRAMS	2	ROOM LAMP AND LUGGAGE COMPARTMENT LAMP	36
ENGINE COMPARTMENT	2	TURN-SIGNAL LAMP AND HAZARD LAMP	38
DASH PANEL	6	STOP LAMP	41
FLOOR, ROOF, AND SEAT	10	BACK-UP LAMP	42
LUGGAGE COMPARTMENT	12	OIL PRESSURE WARNING LAMP	43
SINGLE PART INSTALLATION POSITION	13	CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM>	44
RELAY	13	HEATER AND MANUAL AIR CONDITIONER	48
ECU	14	FULLY AUTOMATIC AIR CONDITIONER	54
SENSOR	14	WINDSHIELD WIPER AND WASHER <INTERMITTENT WIPER>	61
SOLENOID VALVE	16	REAR WIPER AND WASHER	62
CHECK CONNECTOR AND SPARE CONNECTOR	17	DEFOGGER AND DOOR MIRROR HEATER <VEHICLES WITHOUT FULLY AUTOMATIC AIR CONDITIONER>	64
FUSIBLE LINK AND FUSE	17	DEFOGGER AND DOOR MIRROR HEATER <VEHICLES WITH FULLY AUTOMATIC AIR CONDITIONER>	66
GROUND CABLE	18	SPARE CONNECTOR FOR RADIO	68
GROUND	18	RADIO <4-SPEAKER, 6-SPEAKER>	70
CIRCUIT DIAGRAM	19	ANTI-LOCK BRAKE SYSTEM (ABS)	74
CENTRALIZED JUNCTION	19	ACTIVE YAW CONTROL SYSTEM (AYC)	80
POWER DISTRIBUTION SYSTEM	20	INTERCOOLER WATER SPRAY SYSTEM	86
STARTING SYSTEM	25		
IGNITION SYSTEM	26		
CHARGING SYSTEM	27		
ENGINE CONTROL SYSTEM	28		
COOLING SYSTEM	34		

WIRING HARNESS CONFIGURATION DIAGRAMS

ENGINE COMPARTMENT





- | | | | |
|-------------|------------------------------|------------|-----------------------------------------------|
| A-01 (2-B) | Brake fluid level switch | A-20 (4-B) | Windshield wiper motor |
| A-03 (1-B) | Noise condenser | A-21 (8-B) | Hydraulic unit <vehicles with ABS> |
| A-04 (1) | Alternator | A-22 (2-B) | Hydraulic unit <vehicles with ABS> |
| A-05 (4-GR) | Alternator | A-23 (2-B) | Waste gate solenoid valve |
| A-09 (1-B) | Starter | A-25 (7-B) | Air flow sensor |
| A-10 (1) | Starter | A-26 (2-B) | Front speed sensor (LH) <vehicles with ABS> |
| A-12 (2-B) | Fuel pressure solenoid valve | A-28 (8-B) | Control harness and front harness combination |
| A-16 (4-B) | Throttle position sensor | | |
| A-18 (6-B) | Idle speed control servo | | |
| A-19 (3-B) | Vehicle speed sensor | | |




36M0211

A-29 (2-B)	Front harness and battery harness combination	A-45 (1)	Horn (RH)
A-33 (1)	Horn (LH)	A-46 (1)	Horn (RH)
A-34 (1)	Horn (LH)	A-47 (2-G)	Rear washer motor
A-35 (2-BR)	Outside air temperature sensor <vehicles with fully automatic air conditioner>	A-48 (2)	Windshield washer motor
A-38 (2-B)	Engine coolant temperature sensor	A-49 (2-BR)	Dual pressure switch
A-39 (1-B)	Engine coolant temperature gauge unit	A-50 (2-B)	Front speed sensor (RH) <vehicles with ABS>





- | | | | |
|------------|----------------------------------|-------------|-------------------------------------------------|
| A-51 (3-B) | Crank angle sensor | A-78 (2-GR) | Side turn signal lamp (LH) |
| A-52 (1-B) | Oil pressure switch | A-80X (5) | Horn relay <vehicles with SRS air bag> |
| A-53 (2-B) | Injector (No.1) | A-82X (5) | Radiator fan relay (LO) |
| A-54 (2-B) | Injector (No.2) | A-84X (5) | Headlamp relay |
| A-55 (2-B) | Injector (No.3) | A-86X (4) | Alternator relay |
| A-56 (2-B) | Injector (No.4) | A-88 (6-B) | Control harness and battery harness combination |
| A-63 (4-B) | O ₂ sensor | A-89 (2-BR) | Front turn signal lamp (LH) |
| A-72 (2-B) | Back-up lamp switch | A-90 (3-B) | Headlamp (LH) |
| A-73 (1-L) | Engine speed detection connector | A-91 (2) | Position lamp (LH) |
| A-74 (1-B) | Fuel pump check connector | A-92 (2-B) | Fog lamp (LH) |
| A-76 (6) | Valve relay <vehicles with ABS> | | |
| A-77 (5) | Motor relay <vehicles with ABS> | | |




- A-94 (4-GR) Radiator fan motor
- A-96 (2-GR) Knock sensor
- A-97 (3-B) Camshaft position sensor
- A-99 (2-B) Condenser fan motor
- A-101 (1) Power steering oil pressure switch
- A-102 (1) Spare connector for fog lamp
- A-103 (2-B) Fog lamp (RH)
- A-104 (2) Position lamp (RH)
- A-105 (3-B) Headlamp (RH)
- A-106 (1-B) A/C compressor assembly
- A-107 (2-BR) Front turn signal lamp (RH)
- A-110 (3-GR) Ignition coil 1
- A-111 (3-GR) Ignition coil 2

- A-112X (4) Radiator fan relay (HI)
- A-113X (4) Condenser fan relay (LO)
- A-114X (4) Condenser fan relay (HI)
- A-116X (4) A/C compressor relay
- A-117 (2-GR) Side turn signal lamp (RH)
- A-123 (5-B) Fuel pump relay No.2
- A-124 (6-B) Fuel pump resistor
- A-125 (2-B) Resistor (for injector)
- A-126 (5-B) AYC relay
- A-127 (2-B) Secondary air control solenoid valve
- A-128 (2-GR) Condenser fan motor
- A-129 (2-B) Water spray motor
- A-131 (1-B) Noise condenser


DASH PANEL




- | | | | |
|-------------|-------------------------------------------------------------------------------------------------------|-----------|-------------------------------------------------------|
| B-01 (2-R) | Passenger seat air bag module (squib) | B-09 (25) | Meter and gauge |
| B-02 (2) | Heater water temperature sensor <vehicles with fully automatic air conditioner> | B-10 (22) | Body harness and front door harness (RH) combination |
| B-03 (2-B) | Air thermo sensor <vehicles with fully automatic air conditioner> | B-11X (8) | Rear intermittent wiper relay |
| B-04 (20-B) | A/C-ECU <vehicles with fully automatic air conditioner> | B-13X (5) | Power window relay |
| B-05 (16-B) | A/C-ECU <vehicles with fully automatic air conditioner> | B-15 (20) | Front harness and body harness combination |
| B-06 (6) | Air outlet change-over damper motor and potentiometer <vehicles with fully automatic air conditioner> | B-16 (6) | Front harness and body harness combination |
| B-07 (8) | Blower switch <vehicles with manual air conditioner> | B-17 (14) | Front harness and body harness combination <ABS> |
| B-08 (25) | Meter and gauge | B-18 (19) | Jumper connector (1) |
| | | B-19 (22) | Body harness and instrument panel harness combination |




B-21 (2)	Stop lamp switch	B-34 (4)	Blower high speed relay <vehicles with fully automatic air conditioner>
B-22 (16-B)	Diagnosis connector	B-35 (22)	Body harness and front door harness (LH) combination
B-24 (26-Y)	ABS-ECU	B-36 (2)	Inside and outside air change-over damper motor <vehicles with fully automatic air conditioner>
B-25 (22-Y)	ABS-ECU	B-37 (4)	Power transistor <vehicles with fully automatic air conditioner> or resistor <vehicles with heater or manual air conditioner>
B-26 (2-B)	Diode (for ABS circuit)		
B-27 (4)	Engine control relay		
B-28 (4)	Fuel pump relay		
B-30 (14)	Radio or spare connector for radio		
B-31 (1)	Glass antenna amplifier		
B-32 (19-B)	Jumper connector (5)		
B-33 (2)	Blower motor <vehicles with fully automatic air conditioner>		



- | | | | |
|------------|----------------------------------------------------------------------------------------|-------------|-------------------------------------------------------------------|
| B-38 (2) | Sunlight sensor <vehicles with fully automatic air conditioner> | B-44 (6) | Body harness and roof harness combination <vehicles with sunroof> |
| B-39 (6) | Air mix damper motor and potentiometer <vehicles with fully automatic air conditioner> | B-45 (2-B) | Diode (for keyless entry system circuit) |
| B-40 (3) | Automatic compressor ECU <vehicles with manual air conditioner> | B-46 (2) | Spare connector for fog lamp switch <vehicles without fog lamp> |
| B-41 (8) | A/C switch <vehicles with manual air conditioner> | B-48 (14) | Jumper connector (2) |
| B-42 (2) | Blower switch illumination lamp <vehicles with heater or manual air conditioner> | B-49 (14) | Jumper connector (3) |
| B-43 (6-B) | Defogger switch <vehicles with heater or manual air conditioner> | B-50 (14-L) | Jumper connector (4) |
| | | B-51 (21-Y) | SRS-ECU |
| | | B-52 (16-B) | Control harness and body harness combination <vehicles with ABS> |





<Vehicles without interior relay box>




- B-59 (26-Y) Engine-ECU
- B-60 (16-Y) Engine-ECU
- B-61 (12-Y) Engine-ECU
- B-62 (22-Y) Engine-ECU
- B-63 (2) Blower motor <vehicles with heater or manual air conditioner>
- B-64 (13) Control harness and body harness combination

- B-65 (16-B) Control harness and body harness combination
- B-94 (13) Control harness and body harness combination <vehicles with AYC>
- B-95 (26) AYC-ECU
- B-96 (16) AYC-ECU
- B-99 (12) Diagnosis connector

FLOOR, ROOF, AND SEAT





- | | | | |
|-----------|-----------------------------------------------------|-------------|-----------------------------------------------------|
| D-01 (20) | Receiver
<vehicles with keyless entry system> | D-09 (1) | Map lamp |
| D-02 (2) | Seat belt switch | D-10 (18) | Sunroof ECU |
| D-03 (2) | Front door switch (RH) | D-11 (2-GR) | Room lamp <vehicles without sunroof> |
| D-04 (10) | Body harness and fuel harness combination | D-12 (8) | Sunroof motor |
| D-05 (6) | Body harness and rear door harness (RH) combination | D-13 (3-B) | Fuel gauge unit (sub) |
| D-06 (22) | Body harness and rear harness combination | D-14 (2-B) | Rear speed sensor (LH)
<vehicles with ABS> |
| D-07 (6) | Sunroof switch | D-16 (6) | Body harness and rear door harness (LH) combination |
| D-08 (8) | Room lamp <vehicles with sunroof> | D-17 (2) | Front door switch (LH) |
| | | D-18 (6) | Fuel gauge unit (main) |



- D-19 (2-B) Rear speed sensor (RH)
<vehicles with ABS>
- D-20 (3-B) Acceleration sensor <vehicles with ABS>
- D-21 (1-B) Parking brake switch
- D-27 (2) Body harness and rear harness combina-
tion <vehicles with AYC>

- D-31 (2) Water spray switch
- D-32 (3-B) Acceleration sensor (lateral)
<vehicles with AYC>

LUGGAGE COMPARTMENT




36M0204

- | | | | |
|-------------|----------------------------------------------------------------------|-------------|-------------------------------------------------|
| F-01 (1-B) | Defogger (-) <vehicles without choke coil> | F-18 (2-GR) | Licence plate lamp (LH) |
| F-02 (1-B) | Defogger (-) <vehicles with choke coil> | F-20 (6) | Rear combination lamp (LH) |
| F-03 (2) | Choke coil | F-23 (2-B) | Rear speaker (LH) |
| F-04 (3) | Choke coil | F-24 (1) | Glass antenna |
| F-05 (2) | Luggage compartment lamp | | <vehicles with diversity glass antenna> |
| F-06 (2) | Vacant connector or high mounted stop lamp (installed on rear shelf) | F-25 (1) | Glass antenna |
| | | F-26 (1-B) | Rear door switch (LH) |
| F-08 (2-B) | Rear speaker (RH) | F-27 (3-B) | Proportioning valve <vehicles with AYC> |
| F-09 (1-B) | Defogger (+) <vehicles with choke coil> | F-28 (2-B) | Direction valve (LH) <vehicles with AYC> |
| F-10 (1-B) | Defogger (+) <vehicles without choke coil> | F-29 (2-B) | Direction valve (RH) <vehicles with AYC> |
| F-11 (3) | Rear wiper motor | F-30 (8-B) | Rear harness and AYC harness combination |
| F-12 (1-B) | Rear door switch (RH) | | |
| F-13 (2) | High mounted stop lamp (installed on rear spoiler) | F-31 (2-B) | Accumulator pressure switch <vehicles with AYC> |
| F-15 (6) | Rear combination lamp (RH) | F-32 (2-B) | AYC motor |
| F-16 (2-GR) | Licence plate lamp (RH) | F-33 (6) | CD changer |
| F-17 (1-B) | Luggage compartment lamp switch | | |




SINGLE PART INSTALLATION POSITION

RELAY


Name	Symbol	Name	Symbol
AYC relay	B	Fuel pump relay No.2	B
Condenser fan motor relay (HI)	A	Radiator fan motor relay (HI)	A
Condenser fan motor relay (LO)	A	Radiator fan motor relay (LO)	C




16M0429



ECU




B21A086




16M0423

SENSOR










Name	Symbol	Name	Symbol
Acceleration sensor (lateral) <vehicles with AYC>	I	Knock sensor	B
Acceleration sensor (longitudinal) <vehicles with ABS and AYC>	I	Outside air temperature sensor <vehicles with fully automatic air conditioner>	F
Air flow sensor	D	O ₂ sensor	E
Camshaft position sensor	G	Steering angle sensor (lateral) <vehicles with AYC>	H
Crank angle sensor	A	Throttle position sensor	C
Engine coolant temperature sensor	G		



16M0429





B21A086




SOLENOID VALVE

Name	Symbol	Name	Symbol
Direction valve <vehicles with AYC>	D	Secondary air control solenoid valve	A
Fuel pressure solenoid valve	B	Waste gate solenoid valve	C
Proportioning valve <vehicles with AYC>	D		




0040011


16M0429




16M0433



16M0405




16M0116




16M0409


CHECK CONNECTOR AND SPARE CONNECTOR





16M0429




FUSIBLE LINK AND FUSE





16M0429




GROUND CABLE




16M0429



GROUND



16M0429




CIRCUIT DIAGRAM

CENTRALIZED JUNCTION

CENTRALIZED RELAY


Connector No.	Name	Connector No.	Name
A-82X	Radiator fan motor relay (LO)	A-113X	Condenser fan motor relay (LO)
A-112X	Radiator fan motor relay (HI)	A-114X	Condenser fan motor relay (HI)

Relay box in engine compartment





16M0141


(A/C relay box)




16M0142

POWER DISTRIBUTION SYSTEM






POWER DISTRIBUTION SYSTEM (CONTINUED)



(B-67)




(B-76)




(B-83)







POWER DISTRIBUTION SYSTEM (CONTINUED)





(B-73) (B-76)




STARTING SYSTEM



ENGINE CONTROL SYSTEM





(B-60)

31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46

(B-62)

71	72	73	74	75	76	77	78	79	80	81
82	83	84	85	86	87	88	89	90	91	92

(B-64)

1	2	3	▽	4	5	6
7	8	9	10	11	12	13

(B-65)

1	2	3	▽	4	5	6	7	
8	9	10	11	12	13	14	15	16

(B-73)

1


(B-75)


1	2	3	▽	4	5	6	7	
8	9	10	11	12	13	14	15	16

(B-76)

1	2	3	4
5	6	7	8

ENGINE CONTROL SYSTEM (CONTINUED)





- CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM>
- FULLY AUTOMATIC AIR CONDITIONER

(B-50)

(B-59)

(B-61)

(B-62)

(B-64)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26


51	52	53	54	55	56
57	58	59	60	61	62

71	72	73	74	75	76	77	78	79	80	81
82	83	84	85	86	87	88	89	90	91	92


1	2	3	▽	4	5	6
7	8	9	10	11	12	13

ENGINE CONTROL SYSTEM (CONTINUED)







COOLING SYSTEM




- INPUT SIGNAL
- A/C SWITCH
 - IDLE SWITCH
 - CRANK ANGLE SENSOR
 - VEHICLE SPEED SENSOR
 - ENGINE COOLANT TEMPERATURE SENSOR
 - THROTTLE POSITION SENSOR







ROOM LAMP AND LUGGAGE COMPARTMENT LAMP



NOTES

TURN-SIGNAL LAMP AND HAZARD LAMP





(B-68)





(B-69)

(B-75)


(B-76)

(B-86)

(C-02)



TURN-SIGNAL LAMP AND HAZARD LAMP (CONTINUED)



(B-09)

1	2	3	4	5	6	7	8	9	10	11	12
						13					
14	15	16	17	18	19	20	21	22	23	24	25

(B-50)

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16		

(B-75)

1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(B-80)

1	2	3	4	5	6
7	8	9	10	11	12
13	14	15	16		

(B-86)

1	2	3	4
5	6	7	8
9	10		

(D-06)

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22								


(F-15)

1	2
3	4
5	6


(F-20)

1	2
3	4
5	6

STOP LAMP




(B-15)




(B-21)



(B-50)



(D-06)




(F-06)



(F-13)








(F-15)




(F-20)



BACK-UP LAMP



OIL PRESSURE WARNING LAMP



(A-52)




(A-88)

(B-08)


(B-65)






(B-75)

(B-76)




CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM>





CENTRAL DOOR LOCKING SYSTEM <VEHICLES WITH KEYLESS ENTRY SYSTEM> (CONTINUED)



(B-08)

31	32	33	34	35	36	37	38	39	40	41	42
				43							
44	45	46	47	48	49	50	51	52	53	54	55

(B-22) FRONT VIEW

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

(B-49)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-50)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-66)


1	2
---	---

(B-75)


1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

(B-76)


1	2	3	4
5	6	7	8



(B-80)




(D-01)



(D-03)



(D-06)




(D-08)



(D-09)



(D-11)



(D-17)





(F-12)





(F-26)




HEATER AND MANUAL AIR CONDITIONER





HEATER AND MANUAL AIR CONDITIONER (CONTINUED)






HEATER AND MANUAL AIR CONDITIONER (CONTINUED)




NOTES


FULLY AUTOMATIC AIR CONDITIONER




(B-04)




(B-05)



(B-15)



(B-19)



(B-33)




(B-34)




(B-37)




(B-39)




(B-80)




(B-86)







(B-48)




(B-49)



(B-67)



(B-69)




(B-72)



(B-73)




(B-75)




(B-76)



FULLY AUTOMATIC AIR CONDITIONER (CONTINUED)



FULLY AUTOMATIC AIR CONDITIONER (CONTINUED)



(A-28)



(A-82X)



(A-94)



(A-99)



(A-112X)



(A-113X)




(A-114X)




(A-128)






(B-59)







FULLY AUTOMATIC AIR CONDITIONER (CONTINUED)




WINDSHIELD WIPER AND WASHER <INTERMITTENT WIPER>




(A-20) (A-48) (B-15)




(B-18)




(B-50)




(B-64)




(B-74)





(B-76)



(B-81)




REAR WIPER AND WASHER




NOTES


DEFOGGER AND DOOR MIRROR HEATER <VEHICLES WITHOUT FULLY AUTOMATIC AIR CONDITIONER>




(B-10)




(B-15)



(B-19)




(B-35)




(B-43)



(B-48)



(D-06)



(E-01)



(E-17)



(F-01)



(F-02)



(F-03)



(F-04)




(F-09)




(F-10)






(B-50)



(B-69)




(B-71)




(B-73)



(B-74)




(B-75)




(B-76)




(B-80)




(B-86)



**DEFOGGER AND DOOR MIRROR HEATER
 <VEHICLES WITH FULLY AUTOMATIC AIR CONDITIONER>**




(B-04)




(B-05)



(B-10)



(B-35)




(B-71)




(B-73)



(B-74)





(B-76)

1	2	3	4
5	6	7	8

(B-80)

1	2	3	4	5	6	
7	8	9	10	11	12	13

(D-06)

1	2	3	4	5	6	7	8	9	10		
11	12	13	14	15	16	17	18	19	20	21	22

(E-01)

1	2	3	
4	5	6	7

(E-17)

1	2	3	
4	5	6	7

(F-01)

1

(F-02)

1

(F-03)

1
2

(F-04)

1	
2	3










(F-09)


1

(F-10)

1

SPARE CONNECTOR FOR RADIO





(B-35)

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22								

(B-48)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-49)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				

(B-64)

1	2	3	4	5	6
7	8	9	10	11	12
13					

(B-69)

1	2	3	4	5	6
7	8	9	10	11	12
13	14				


(B-73)

1

(B-74)

1	2	3	4	5
6	7	8	9	10

RADIO <4-SPEAKER, 6-SPEAKER>



(B-10)

1	2	3	4	5	M	6	7	8	9	10	
11	12	13	14	15	16	17	18	19	20	21	22

(B-15)

1	2	3	4	M	5	6	7	8	9	
10	11	12	13	14	15	16	17	18	19	20

(B-19)

1	2	3	4	5	M	6	7	8	9	10	
11	12	13	14	15	16	17	18	19	20	21	22

(B-30)

1	2	3	M	4	5	6	
7	8	9	10	11	12	13	14

(B-31)

1

(B-35)

1	2	3	4	5	M	6	7	8	9	10	
11	12	13	14	15	16	17	18	19	20	21	22

(D-06)

1	2	3	4	5	M	6	7	8	9	10	
11	12	13	14	15	16	17	18	19	20	21	22

(E-02)

M
1 2

(E-11)

1
2

(E-16)

M
1 2

(E-18)

1
2

(F-08)

1
2

(F-23)



1
2

(F-24)


1

(F-25)


1




(B-48)



(B-49)




(B-69)



(B-73)




(B-75)




(B-76)










(B-80)



(B-86)




RADIO <4-SPEAKER, 6-SPEAKER> (CONTINUED)



NOTES

ANTI-LOCK BRAKE SYSTEM (ABS)



(B-15)

1	2	3	4	5	6	7	8	9		
10	11	12	13	14	15	16	17	18	19	20

(B-21)

1
2

(B-24)

1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26

(B-25)

31	32	33	34	35	36	37	38	39	40	41
42	43	44	45	46	47	48	49	50	51	52

(B-32)



1	2	3	4	5	6	7	8			
9	10	11	12	13	14	15	16	17	18	19

(B-49)


1	2	3	4	5	6		
7	8	9	10	11	12	13	14

(B-95)


1	2	3	4	5	6	7	8	9	10	11	12	13
14	15	16	17	18	19	20	21	22	23	24	25	26




ANTI-LOCK BRAKE SYSTEM (ABS) (CONTINUED)




(A-26)	(A-50)	(A-76)	(A-77)	(B-08)	(B-09)	(B-17)	(B-24)
1 2	1 2	1 2 3 4 5 6	1 2 3 4 5	31 32 33 34 35 36 37 38 39 40 41 42 43	1 2 3 4 5 6 7 8 9 10 11 12 13	1 2 3 4 5 6 7 8 9 10 11 12 13 14	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 24 25 26




(B-25)



(B-52)




(B-75)



(B-76)



(D-04)



(D-14)



(D-19)





(D-20)



(D-32)





ANTI-LOCK BRAKE SYSTEM (ABS) (CONTINUED)










NOTES

ACTIVE YAW CONTROL SYSTEM (AYC)




ACTIVE YAW CONTROL SYSTEM (AYC) (CONTINUED)







(B-52)




(B-65)



(B-95)




(B-96)



(B-98)



(D-04)









(D-14)




(D-19)



ACTIVE YAW CONTROL SYSTEM (AYC) (CONTINUED)





(B-96)

31	32	33	34	35	36	37	38
39	40	41	42	43	44	45	46

(D-06)

1	2	3	4	5	6	7	8	9	10		
11	12	13	14	15	16	17	18	19	20	21	22

(D-27)

1	2
---	---

(F-27)

1	2	3
---	---	---

(F-28)

1	2
---	---

(F-29)

1	2
---	---

(F-30)

1	2	3	4
5	6	7	8


(F-31)

1	2
---	---

(F-32)

1	2
---	---

INTERCOOLER WATER SPRAY SYSTEM



- ACTIVE YAW CONTROL SYSTEM
- ANTI-LOCK BRAKE SYSTEM

