
POWER PLANT MOUNT

CONTENTS


ROLL STOPPER AND CENTERMEMBER 2



ROLL STOPPER AND CENTERMEMBER

REMOVAL AND INSTALLATION

Caution
 When tightening the portion marked with *, first temporarily tighten it, then torque to specification with the engine weight applied to the body.



01M0176

Unit: Nm {kgf · m}

Removal steps



1. Front crossmember bar <vehicles with 17' wheels>
2. Bolt
3. Front roll stopper bracket assembly
4. Rear roll stopper bracket assembly
5. Centermember

NOTE

The conventional service procedures apply for the installation service points.